


Current Status of Access Routines to ENDF Data in AMPX

Dorothea Wiarda

WPEC 2017 – Subgroup 43

Paris, France
May 16, 2017

ORNL is managed by UT-Battelle
for the US Department of Energy



OAK RIDGE
National Laboratory

Outline


- Current status of ENDF processing in AMPX
 - In-memory containers for AMPX and SCALE data
 - How do the processing codes use the in-memory containers
 - Interaction between ENDF data and in-memory containers
- Current status of GND basic containers in AMPX
 - Definition for aliases for GND data types
 - Base container classes
 - Values container
 - Other containers

AMPX and SCALE Philosophy


- Use in-memory container for data:
 - C++ resource for MG library
 - C++ resource CE library
 - C++ resource for COVERX formatted covariance libraries
 - C++ resource for resonance parameters
 - and many others
- If possible pass data in-memory not via disk I/O
- Where applicable, in-memory data containers have a FORTAN binding.

Library generation in AMPX


Codes producing final libraries.
Using SCALE and AMPX in-memory formats



Processing of kinematic data



Resonance API



- SLBW and MLBW parameter are stored in the same class with a flag indicating which formalism to use
- Resonance parameters for Reich-Moore for LRF=3 are initially stored in a different class, but are converted to a LRF=7 class before calculation
- If derivatives are desired, all formalisms (except URR) are converted to LRF=7 so SAMRML can be used under the hood
- All resonance parameter classes can contain a covariance matrix. If converting to a different formalism, the covariance matrix is re-organized accordingly

Fill AMPX data structures from ENDF

- Processing routines call a function with arguments:
 - type: string of the desired format, currently only "endf" is allowed
 - out: input stream opened to the file to read
 - Any other arguments that might be needed for the relevant data. For example the kinematic data can be retrieved for exiting neutrons only.
- The result is an in-memory AMPX data container with the relevant ENDF data filled in.
- The above routine determines what class to call to read the data. All legacy *endf* format related classes are collected in a different directory and name space. The *gnd* format has a different name space.
- Examples are:
 - *getKinematicRawData*
 - *getResonanceInfo*
 - *retrieveCovariance*

Structure of the legacy ENDF classes

- Base class (Record) that contains MAT, MT and MF values along with routines to read and write the right part of an ENDF record
- Classes that inherit from Record for *text*, *list*, *tab1*, *tab2* and *intg* ENDF records.
- Classes for each ENDF file, that either directly fill an in-memory AMPX class (File 8) or read and store the *text*, *list*, *tab1*, *tab2* and *intg* for later use.
- Classes that combine the varies ENDF file data into the in-memory AMPX record. For example *EndfSetKinematicData* combines data from *File 4, 5, 6, 7, 12, 13, 14, and 15* to generate the data needed for processing in Y12
- All the above classes do not do any processing, just sorting of data into the in-memory AMPX class.

Initial GND processing in AMPX

Definitions for GND general containers

Add a definition file that sets aliases for the different GND data types:

- Link *Float32* to C++ *float* and *Float64* to C++ *double*, etc.
 - In the remaining code always use GND data types
- Add template function to parse GND data types from text and to save to text.
 - Add instantiations for all allowed GND data types
- Add a templated function to get the default value for a GND data type
 - Add instantiations for all allowed GND data types
- Add enumerations for the type of allowed interpolations (*lin-lin*, *flat*, etc.) with the corresponding text to be used for on-disk representation of GND

Access to the GND files

Interface class
Attribute

getName
setName
getValue
setValue

Interface class
Element

getNumAttribute
getAttribute
getNumElements
getElement
getValue
getValueData
....
Setter functions

Interface class
EndfDocument

getRootElement
createRootElement

- An implementation for these classes currently exists, using QT XML classes.
- All AMPX GND classes only use the interface class
- The *getValueData* and *setValueData* functions are templated functions to take arrays of a specified GND data types. This should allow future on-disk formats to save the data as binary float or double data to preserve precision.

ValueData class

ValueData

Templated:

getValue

setValue

setValueType (type, data)

setTypeNames

getTypeNames

Private shared pointer
to each of the GND
data types

- *ValueData* class represent the optional value and valueType attributes of a functional container.
- One or none of the private shared pointer data to the various GND data types is different from NULL.
- *getValue* returns NULL if the *ValueData* is not of the desired type.

Container base class

Container

getLabel
setLabel

getIndex
setIndex

setValueData
getValueData

readFromElement
saveToElement

getElementName
isAcceptableName

- Container class that serves as base class for all other containers
- Combines common attributes of all containers and functional containers.
- Functions to interact with Element and Attribute interface classes. Child classes will first call these functions and then supplement.

ValueData and ValuesContainerHolder

Template class
ValueData
extends *Container*

getStart
setStart

getLength
setLength

getSize
setSize

setValue
getValue

Inherited functions

- *ValueData* is a template class that implements the values container
- *ValuesContainerHolder* has a shared pointer to a *ValueData* object for each of the GND data types.
- One or none of the above pointers can be different from NULL.
- Convenience functions with implementations for all GND data types allow to get the underlying *ValueData*.

Remaining general data containers

- Classes for all the remaining general data containers have been added.
- If the container contains a gnd “values container”, one or more shared pointer for *ValuesContainerHolder* objects are added.
- If applicable, templates functions are added to get the data directly. For example:
 - The *ArrayContainer* for the array container has a templated function that takes a vector of indices to get or set the value of the matrix directly.
 - The *TableContainer* for the table container breaks the data into columns and each column in turn contains a *ValuesContainerHolder* object. This allows easy access to the data for a given row and column.
- Unit tests have been added for all classes in the base container package.

Summary

- AMPX uses in-memory structures to hold ENDF data.
- The structures are not dependent on the on-disk ENDF format.
- Processing routines only use the in-memory data, and do not read ENDF data directly.
- An implementation of the GND base containers has been added to AMPX in preparation for processing of the GND file.